

NOTES:

1. Volume, Tone, input connector and 5W / 1W Switch are located on the front panel board.
2. Power switch, fuse and LED are located on the AC power board.
3. External speaker connector and R8 are located on the rear panel board.
4. Transformers are chassis mounted.
5. D1 - D4 are 1N4007.
6. VR2 replaced with C250K.

Title Monoprice 5W Tube Amp		
Author Drawn by: Chuck D. Bones		
File D:\Users\Chuck Bones\My Documents\ ... 5W.dsn		Document 611705
Revision 1.0	Date 22-July-2019	Sheets 1 of 1